

# Headsets / Portabler Freisprech-Kit

## Kompatibilität Mobiltelefone

Artikel	Marke	Model
19040	Blackberry	5810 / 6210 / 6230 / 6280 / 6510 / 6710 / 6720 / 6750 / 7100v / 7100g / 7100t / 7100i / 7105t / 7100v / 7100x / 7130e / 7210 / 7230 / 7250 / 7280 / 7290 / 7510 / 7730 / 7750 / 7780 / 8700c / 8700G / 8700v / 8700f/8707v / 8100 Pearl / 8800 Pearl / 8820
19087	Motorola	T270 / T280 / T288 / T720 / C115 / C139 / C155 / C156 / C157 / C200 / C230 / C250 / C270 / C300 / C330 / C336 / C350 / C359 / C380 / C385 / C390 / C450 / C550 / C650 / C698 / C975 / C980 / V50 / V60 / V66 / V70 / V80 / V150 / V171 / V180 / V186 / V220 / V262 / V265 / V280 / V290 / V300 / V303 / V360 / V500 / V501 / V505 / V525 / V545 / V547 / V550 / V551 / V560 / V600 / V620 / V635 / V680 / V690 / V730 / V860 / V868 / V872 / V878 / V880 / V980 / V1050 / A630 / / A668 / A760 / A768 / A780 / A820 / A830 / A835 / A840 / A920 / A925 / A1000 / A1010 / E310 / E360 / E365 / E380 / E390 / E398 / E550 / E680 / E680i / E815 / E1000 / E1060 / E1120 / P768i / L7089 / MPX / MPX100 / MPX200 / MPX220 / A728 / E378i / ROKR E1 / C118
19088	Motorola	RAZRV3 / V3x / V3i / PEBLU6 / E770 / SLVRL6 / L7 / E1070 / BLK/Rarz V3c / L2 / KRZRK1 / Z3 / RAZRMAXX / RAZRV3XX / RAZR / V360 / A910 / RIZR Z6 / Z8 / E770V / E6 / W218 / W360 / KRZR K3 / MAXX V6
19014	Nokia	252 / 1100 / 1101 / 1108 / 1110 / 1112 / 1600 / 2100 / 2300 / 2600 / 2610 / 2650 / 2652 / 3210 / 3310 / 3315 / 3330 / 3360 / 3390 / 3410 / 3510 / 3510i / 3590 / 3610 / 3650 / 3660 / 5210 / 5510 / 6030 / 6060 / 6236i / 6510 / 6590 / 6600 / 7280 / 7380 / 7390 / 7650 / 8210 / 8250 / 8260 / 8290 / 8310 / 8390 / 8800 / 8801 / 8850 / 8855 / 8890 / 8910 / 8910i / N-qage
19015	Nokia	3285 / 3530 / 5110 / 5130 / 5120 / 5160 / 5190 / 6110 / 6120 / 6150 / 6160 / 6161 / 6162 / 6190 / 6210 / 6250 / 6310 / 6310i / 6340 / 6370 / 7100 / 7110 / 7190 / RinGo
19016	Nokia	2652 / 2626 / 3100 / 3108 / 3120 / 3200 / 3205 / 3220 / 3230 / 3250 / 3300 / 5100 / 5140 / 5140i / 6020 / 6021 / 6070 / 6100 / 6101 / 6103 / 6108 / 6111 / 6125 / 6131 / 6136 / 6170 / 6220 / 6225 / 6230 / 6230i / 6233 / 6234 / 6260 / 6270 / 6280 / 6585 / 6610 / 6610i / 6620 / 6630 / 6650 / 6670 / 6680 / 6681 / 6800 / 6810 / 6820 / 6822 / 7200 / 7210 / 7250 / 7250i / 7260 / 7270 / 7360 / 7370 / 7600 / 7610 / 7700 / 7710 / 9300 / 9300i / 9500 / N70 / N71 / N80 / N90 / N92 / E60 / E61 / E61i / E65 / E70 / N93 / N93i / N73 / N76 / E50 / 7373 / 6290 / 6086 / 6120C / N80i
19019	Panasonic	GD86A / GD87 / GD88 / X60 / X66 / X68 / X200 / X400 / X700 / A500
19020	Panasonic	X70
19123	Samsung	C200N / C207 / C225 / D357 / D410 / D415 / S300 / S307 / S308 / E105 / E330 / E335 / E608 / E705 / E710 / E715 / E808 / E810 / C100 / C110 / X105 / X120 / X426 / X427 / X430 / X460 / X475 / X480 / X495 / X497 / X507 / X610 / P107 / P510 / T309 / i300x / C140 (the size is different with NK-3210)
19124	Samsung	D307 / D500 / D508 / D600 / D730 / E300 / E315 / E316 / E317 / E340 / E350 / E530 / E568 / E610 / E620 / E630 / E635 / E720 / E728 / E730 / E738 / E760 / E780 / E800 / E820 / E850 / E880 / Z107 / Z110 / Z130 / Z140 / Z300 / Z320i / Z500 / ZV10 / ZM60 / P207 / P730 / P735 / P777 / S341i / S342i / X138 / X140 / X620 / X660 / X680 / i300 / E770 / E370 / SGH / X700 / P200 / P300 / i320 / E840
19122	Samsung	A100 / A110 / A188 / A300 / A400 / N150 / i700 / A580
1917	Sharp	GX 20
19171	Sharp	GX 30
19017	Siemens	A52 / A55 / A56 / A57 / A60 / A62 / A65 / A70 / A75 / AX72 / AX75 / C6 / C50 / C55 / C56 / C60 / C61 / C62 / C65 / C72 / C75 / CT56 / CF62 / CF63 / CF75 / CL65 / CL75 / CX65 / CX70 / CX75 / CXV65 / CV65 / CFX65 / CF110 / CT66 / SX1 / S55 / S56 / S57 / S65 / S66 / S75 / SL55 / SL56 / SL65 / SL75 / ST60 / SF65 / SK65 / SP65 / SXG75 / M55 / M56 / M65 / M75 / MC60 / ME75 / MCT62 / Xelibri 1 / Xelibri 2 / Xelibri 3 / Xelibri 4 / Xelibri 5 / Xelibri 6 / Xelibri 7 / Xelibri 8
19018	Siemens	ST55
19074	Siemens	C / S 25 / A / C / M / S 35 / SL 42 / C / S 45
19076	Siemens	ME45 / SL45
19032	Sony Ericsson	T20e / T20S / T28 / T29 / T38 / T39m / T60 / T61Z / T62 / T68 / T65 / T66 / T67 / T68i / T100 / T102 / T105 / T106 / T200 / T202 / T206 / T226 / T230 / T237 / T238 / T300 / T302 / T306 / T310 / T312 / T316 / T320 / T600 / T606 / T608 / T610 / T616 / T618 / T628 / / T630 / T637 / R290 / R310 / R300Z / R300Lx / R320 / R380 / R520m / R520 / R600 / A2218 / A2218Z / A2288 / A2618 / A2628 / A3618 / Z200 / Z300i / Z208 / Z500 / Z600 / Z608 / Z630 / Z700 / Z800i / Z1010 / S700 / S700i / S710 / P800 / P802 / P900 / P908 / P910 / P910i / K300i / F500i / K300i / K500i / K506c / K508i / K508c / K600i / K608i / K700 / K700i / J200c / J200i / J300i / T290i / V600i / V800 / J210i / W600i
19033	Sony Ericsson	K310i / K610i / K750i / D750i / S600i / W200i / W300i / W550i / W610i / W660 / W700i / W800i / W810i / W900i / W910 / W950i / W960 / P990i / J100i / J220i / J230i / M600i / Z200i / Z310i / Z320i / Z520i / Z530i / Z550i / Z710i / W850i / W710i / k510i / K550i / K290i / K630i / V630i / K770i / K790i / K800i / K810i / K510i / V630 / Z558i / Z610i / K850i / P1i / T650i / V640i
19041	-	MDA Comfort, Qtek S100
1900	Zubehör	Schaumstoffkappe